

NINGBO EVERRISING

12 YEARS

PROFESSIONAL MANUFACTURE



SWITCH&SOCKET



NEIEC

TEL:0086-574-27872111 87292322 87707157

FAX:0086-574-27872333 87292320

<http://www.neiec.cn>

E-mail:neiec@neiec.cn

FACOTRY:

NO.118 Meijing Road,High-Tech Zone,Ningbo,China



12
YEARS
PROFESSIONAL
NINGBO EVERRISING
<http://www.neiec.cn>

Company Profile

Ningbo Everrising Import&Export Co., Ltd. is a professional exporter of electronic and electrical accessories and home appliance. Our products include switches, socket, plugs, lamp holders, junction boxes, power adapters, cables, electrical testers, heater elements, fluorescent tubes, circular fluorescent tubes, energy saving lamps, halogen lamps, ceiling fan, standing fan, electric iron, rice cooker etc

With the principle of honesty and sincerity, we insist on aiming at providing customers with reliable quality, reasonable prices and excellent packaging services. Although our company is only for several years, the work team is quite professional in foreign trade.

With almost a decade of experience in this field, we have established strong and long-term business relationships with dozens of manufactures, which enable us to meet various customers' demands. Our products are popular with importers and wholesalers from more than 30 countries and regions all around the world.

Meanwhile, we are looking forward to further development with customers on the basis of equality and mutual benefit. If you are interested in our products, please feel free to contact us.



12
YEARS
PROFESSIONAL
NINGBO EVERRISING
<http://www.neiec.cn>

SWITCH&SOCKET
ZINC ALLOY

MEA SERIES

★ **High-end**



MEA301
1Gang 1Way Switch

MEA302
1Gang 2Way Switch



MEA303
2Gang 1Way Switch

MEA304
2Gang 2Way Switch



MEA305
3Gang 1Way Switch


MEA306
3Gang 2Way Switch



MEA324
20A DP Switch with Neon



MEA327
45A DP Switch with Neon



MEA407
13A 1Gang Switched Socket with Neon



MEA431
15A 1Gang Switched Socket with Neon



MEA438
TEL Socket



MEA469
TV Socket

MEB SERIES

★ **High-end**



MEB301
1Gang 1Way Switch

MEB302
1Gang 2Way Switch



MEB303
2Gang 1Way Switch

MEB304
2Gang 2Way Switch



MEB305
3Gang 1Way Switch

MEB306
3Gang 2Way Switch



MEB324
20A DP Switch with Neon




MEB327
45A DP Switch with Neon




MEB407
13A 1Gang Switched Socket with Neon



MEB431
15A 1Gang Switched Socket with Neon
























MEB438
TEL Socket









MEB469
TV Socket












V1 SERIES

 V1301 1Gang 1Way Switch	 V1303 2Gang 1Way Switch	 V1305 3Gang 1Way Switch
 V1302 1Gang 2Way Switch	 V1304 2Gang 2Way Switch	 V1306 3Gang 2Way Switch
 V1307 4Gang 1Way Switch	 V1308 4Gang 2Way Switch	 V1318 Bell Push Switch
 V1324 20A DP Switch with Neon	 V1327 45A DP Switch with Neon	 V1407M 13A Multi-Function Socket with Neon
 V1405 13A 1Gang Switched Socket	 V1407 13A 1Gang Switched Socket with Neon	 V1429 15A 1Gang Switched Socket
 V1431 15A 1Gang Switched Socket with Neon	 V1406 13A 2Gang Switched Socket	 V1408 13A 2Gang Switched Socket with Neon
 V1442 Computer Socket	 V1452 TEL Socket	 V1432 TV Socket

G SERIES

 G301 1Gang 1Way Switch	 G303 2Gang 1Way Switch	 G305 3Gang 1Way Switch
 G302 1Gang 2Way Switch	 G304 2Gang 2Way Switch	 G306 3Gang 2Way Switch
 G405 13A 1Gang Switched Socket	 G324 20A DP Switch with Neon	 G406 13A 2Gang Switched Socket with Neon

AG SERIES

 AG301 1Gang 1Way Switch	 AG303 2Gang 1Way Switch	 AG305 3Gang 1Way Switch
 AG302 1Gang 2Way Switch	 AG304 2Gang 2Way Switch	 AG306 3Gang 2Way Switch
 AG438 1Gang TEL. Socket	 AG318 Lighting Dimmer	 AG406 13A 2Gang Switched Socket with Neon

MA SERIES

 MA301 1Gang 1Way Switch	 MA303 2Gang 1Way Switch	 MA305 3Gang 1Way Switch
 MA302 1Gang 2Way Switch	 MA304 2Gang 2Way Switch	 MA306 3Gang 2Way Switch
 MA405 13A 1Gang Switched Socket	 MA406 13A 2Gang Switched Socket	 MA429 15A 1Gang Switched Socket



ZY SERIES



ZY301
1Gang 1Way Switch



ZY303
2Gang 1Way Switch



ZY305
3Gang 1Way Switch



ZY302
1Gang 2Way Switch



ZY304
2Gang 2Way Switch



ZY306
3Gang 2Way Switch



ZY307
4Gang 1Way Switch



ZY318
Bell Push Switch



ZY308
4Gang 2Way Switch

ZY324
20A DP Switch with Neon



ZY327
45A DP Switch with Neon



ZY329
45A DP Switch with Neon



ZY407M
13A Multi-Function Socket with Neon



ZY407
13A 1Gang Switched Socket with Neon



ZY408
13A 2Gang Switched Socket with Neon




ZY431
15A 1Gang Switched Socket with Neon



ZY485
13A Multi-Function Socket with Neon



ZY442
Computer Socket



ZY452
TEL Socket



ZY469
Satellite Socket



ZY432
TV Socket

ERB SERIES



ERB301
1Gang 1Way Switch



ERB303
2Gang 1Way Switch



ERB305
3Gang 1Way Switch



ERB302
1Gang 2Way Switch



ERB304
2Gang 2Way Switch



ERB306
3Gang 2Way Switch



ERB324
20A DP Switch with Neon



ERB327
45A DP Switch with Neon(7X7)



ERB329
45A DP Switch with Neon(7X14)



ERB407
13A 1Gang Switched Socket with Neon




ERB407M
13A 1Gang Multi-Function Socket with Neon



ERB485
13A and 16A Multi-Function Socket with Neon



ERB408
13A 2Gang Switched Socket with Neon



ERB408M
13A 2Gang Multi-Function Socket with Neon



ERB485D
13A and 16A Double Multi-Function Socket with Neon




ERB431
15A 1Gang Switched Socket with Neon



ERB432
TV Socket



ERB452
TEL. Socket



hot

A1 SERIES



A1301
1Gang 1Way Switch



A1303
2Gang 1Way Switch



A1305
3Gang 1Way Switch



A1302
1Gang 2Way Switch



A1304
2Gang 2Way Switch



A1306
3Gang 2Way Switch



A1324
20A DP Switch with Neon



A1407
13A 1Gang Switched Socket with Neon



A1431
15A 1Gang Switched Socket with Neon



A1407M
13A Multi-Function Socket with Neon



A1408
13A 2Gang Switched Socket with Neon



A1408M
13A 2Gang Multi-Function Socket with Neon

ZC3 SERIES

New



ZC3301
1Gang 1Way Switch



ZC3303
2Gang 1Way Switch



ZC3307
4Gang 1Way Switch



ZC3325
13A Switch FUSE



ZC3405
13A 1Gang 1Way Switched Socket



ZC3442
Computer Socket

New

GL SERIES



GL301
1Gang 1Way Switch



GL303
2Gang 1Way Switch



GL305
3Gang 1Way Switch



GL302
1Gang 2Way Switch



GL304
2Gang 2Way Switch



GL306
3Gang 2Way Switch



GL307
4Gang 1Way Switch



GL324
20A DP Switch with Neon



GL327
45A DP Switch with Neon



GL308
4Gang 2Way Switch



GL407
13A 1Gang Switched Socket with Neon



GL407M
13A Multi-Function Socket with Neon



GL431
15A 1Gang Switched Socket with Neon



GL555
1Gang 13A Multi socket with neon with 2 USB



GL485
13A Multi-Function +16A Multi-Function socket with neon



GL445
16A 1Gang and 20A Switch



GL408
13A 2Gang Switched Socket with Neon



GL408M
13A 2Gang Multi-Function Socket with Neon



GL220S
Fan Dimmer with Switch



GL452
TEL Socket



GL432
TV Socket



GL220S
Fan Dimmer











E1 SERIES

ACRYLIC

 E1301 1Gang 1Way Switch E1302 1Gang 2Way Switch	 E1303 2Gang 1Way Switch E1304 2Gang 2Way Switch	 E1305 3Gang 1Way Switch E1306 3Gang 2Way Switch
 E1307 4Gang 1Way Switch E1308 4Gang 2Way Switch	 E1324 20A DP Switch with Neon	 E1407M 13A Multi-Function Socket with Neon
 E1431 15A 1Gang Switched Socket with Neon	 E1220 Dimmer Switch	

E4 SERIES

PLASTIC

 E4301 1Gang 1Way Switch E4302 1Gang 2Way Switch	 E4303 2Gang 1Way Switch E4304 2Gang 2Way Switch	 E4305 3Gang 1Way Switch E4306 3Gang 2Way Switch
 E4407 13A 1Gang Switched Socket with Neon	 E4408M 13A 2Gang Multi-Function Socket with Neon	 E4407 1Gang Socket with Earth
 E4442 Computer Socket	 E4469 Satellite Socket	



G2.5 SERIES

 G2.5301 1Gang 1Way Switch G2.5302 1Gang 2Way Switch	 G2.5303 2Gang 1Way Switch G2.5304 2Gang 2Way Switch	 G2.5324 20A DP Switch with Neon
 G2.5327 45A DP Switch with Neon	 G2.5485 13A Multi-Function Socket with Neon	 G2.5431 15A 1Gang Switched Socket with Neon
 G2.5408 13A 2Gang Switched Socket with Neon	 G2.5407 1Gang Socket with Earth	
 G2.5301 1Gang 1Way Switch G2.5302 1Gang 2Way Switch	 G2.5301 1Gang 1Way Switch G2.5302 1Gang 2Way Switch	 G2.5303 2Gang 1Way Switch G2.5304 2Gang 2Way Switch
 G2.5407 13A 1Gang Switched Socket with Neon	 G2.5431 15A 1Gang Switched Socket with Neon	 G2.5407M 13A Multi-Function Socket with Neon
 G2.5432 TV Socket		



G5.3 SERIES



G5.3301
1Gang 1Way Switch

G5.3302
1Gang 2Way Switch



G5.3303
2Gang 1Way Switch

G5.3304
2Gang 2Way Switch



G5.3305
3Gang 1Way Switch

G5.3306
3Gang 2Way Switch



G5.3307
4Gang 1Way Switch

G5.3308
4Gang 2Way Switch



G5.3407
13A 1Gang Switched
Socket with Neon



G5.3407M
13A Multi-Function
Socket with Neon



G5.3408M
13A 2Gang Multi-Function
Socket with Neon



G5.3485
13A Multi-Function
Socket with Neon



G5.3431
15A 1Gang Switched
Socket with Neon



G5.3488
16A 2Gang Switched
Socket



G5.3407
1Gang Socket
with Earth



G5.3407
1Gang Socket
with Earth



G5.3432
TV Socket

ERA SERIES



ERA301
1Gang 1Way Switch

ERA302
1Gang 2Way Switch



ERA303
2Gang 1Way Switch

ERA304
2Gang 2Way Switch



ERA305
3Gang 1Way Switch

ERA306
3Gang 2Way Switch



ERA324
20A DP Switch with
Neon



ERA327
45A DP Switch with
Neon(7X7)



ERA329
45A DP Switch with
Neon(7X14)



ERA407
13A 1Gang Switched
Socket with Neon



ERA407M
13A 1Gang
Multi-Function
Socket with Neon



ERA485
13A and 16A
Multi-Function
Socket with Neon



ERA408
13A 2Gang Switched
Socket with Neon



ERA408M
13A 2Gang
Multi-Function
Socket with Neon



ERA485D
13A and 16A Double
Multi-Function Socket
with Neon



ERA431
15A 1Gang Switched
Socket with Neon






























ERA432
TV Socket



ERA452
TEL. Socket



ZR SERIES

	ZR301 1Gang 1Way Switch		ZR303 2Gang 1Way Switch		ZR305 3Gang 1Way Switch
	ZR302 1Gang 2Way Switch		ZR304 2Gang 2Way Switch		ZR306 3Gang 2Way Switch
	ZR307 4Gang 1Way Switch		ZR318 Bell Push Switch		ZR324 20A DP Switch with Neon
	ZR308 4Gang 2Way Switch		ZR327 45A DP Switch with Neon		ZR329 45A DP Switch with Neon
	ZR327 45A DP Switch with Neon		ZR407M 13A Multi-Function Socket with Neon		ZR405 13A 1Gang Switched Socket
	ZR407M 13A Multi-Function Socket with Neon		ZR407 13A 1Gang Switched Socket with Neon		ZR429 15A 1Gang Switched Socket
	ZR431 15A 1Gang Switched Socket with Neon		ZR408 13A 2Gang Switched Socket with Neon		ZR442 Computer Socket
	ZR431 15A 1Gang Switched Socket with Neon		ZR442M 2 Computer Socket		ZR438 2 TEL Socket
	ZR442M 2 Computer Socket		ZR438 TEL Socket		ZR438M 2 TEL Socket
	ZR469 TV Socket		ZR220 Dimmer switch		



ST SERIES

	ST301 1Gang 1Way Switch		ST303 2Gang 1Way Switch		ST305 3Gang 1Way Switch
	ST302 1Gang 2Way Switch		ST304 2Gang 2Way Switch		ST306 3Gang 2Way Switch
	ST324 20A DP Switch with Neon		ST405 13A 1Gang Switched Socket		ST406 13A 2Gang Switched Socket
	ST429 15A 1Gang Switched Socket		ST432 TV Socket		
	ST301 1Gang 1Way Switch		ST303 2Gang 1Way Switch		ST305 3Gang 1Way Switch
	ST302 1Gang 2Way Switch		ST304 2Gang 2Way Switch		ST306 3Gang 2Way Switch
	ST324 20A DP Switch with Neon		ST405 13A 1Gang Switched Socket		ST432 TV Socket
	ST301 1Gang 1Way Switch		ST302 1Gang 2Way Switch		ST432 TV Socket

G2 SERIES



G2301
1Gang 1Way Switch

G2302
1Gang 2Way Switch



G2305
3Gang 1Way Switch

G2306
3Gang 2Way Switch



G2324
20A 1Gang Switched
Socket with Neon



G2407
13A 1Gang Switched
Socket with Neon



G2408
13A 2Gang Switched
Socket with Neon



G2431
15A 1Gang Switched
Socket with Neon



G2327
45A DP Switch with
Neon



G2465
TV Socket



G2452
TEL. Socket

C3 SERIES



C3303
2Gang 1Way Switch

C3304
2Gang 2Way Switch



C3305
3Gang 1Way Switch

C3306
3Gang 2Way Switch



C3324
20A 1Gang Switched
Socket with Neon



C3405
13A 1Gang Switched
Socket



C3429
15A 1Gang Switched
Socket



C3452
TEL. Socket



C3465
TV Socket

C10 SERIES



C11 SERIES




ZD SERIES



G5 SERIES



WT SERIES



34 SERIES



LK SERIES



LK301
1Gang 1Way Switch



LK303
2Gang 1Way Switch



LK305
3Gang 1Way Switch



LK302
1Gang 2Way Switch



LK304
2Gang 2Way Switch



LK306
3Gang 2Way Switch

SO86 SERIES




SO86301
1Gang 1Way Switch



SO86303
2Gang 1Way Switch



SO86305
3Gang 1Way Switch



SO86302
1Gang 2Way Switch



SO86304
2Gang 2Way Switch



SO86306
3Gang 2Way Switch

SO128 SERIES



B SERIES



B301
1Gang 1Way Switch



B303
2Gang 1Way Switch



B305
3Gang 1Way Switch



B302
1Gang 2Way Switch



B304
2Gang 2Way Switch



B306
3Gang 2Way Switch



B307
4Gang 1Way Switch



B317
Bell Push Switch



B324
20A DP Switch



B308
4Gang 2Way Switch



B327
45A DP Switch with Neon



B331
45A Cooker Unit



B407
13A 1Gang Switched Socket with Neon



B405
13A 1Gang Switched Socket




B406
13A 2Gang Switched Socket



B408
13A 2Gang Switched Socket with Neon



B429
15A 1Gang Switched Socket



B405M
13A Multi-Function Socket





























B452
TEL. Socket

B432
TV Socket

B469
Satelite Socket



Z SERIES

 Z301 1Gang 1Way Switch	 Z302 1Gang 2Way Switch	 Z303 2Gang 1Way Switch	 Z304 2Gang 2Way Switch	 Z305 3Gang 1Way Switch	 Z306 3Gang 2Way Switch
 Z307 4Gang 1Way Switch (7x7)	 Z308 4Gang 2Way Switch (7x7)	 Z307 4Gang 1Way Switch (7x14)	 Z308 4Gang 2Way Switch (7x14)	 Z317 Bell Push Switch	
 Z318 Bell Push Switch with Neon	 Z324 20A DP Switch with Neon	 Z324R 20A DP Switch with Neon			
 Z327 45A DP Switch with Neon	 Z329 45A DP Switch with Neon	 Z331 Cooker Unit			
 Z405 13A 1Gang Switched Socket	 Z407 13A 1Gang Switched Socket	 Z407R 13A 1Gang Switched Socket			
 Z429 15A 1Gang Switched Socket	 Z431 15A 1Gang Switched Socket with Neon	 Z431R 15A 1Gang Switched Socket with Neon			
 Z444 16A 2Gang Multi-Function Socket	 Z490 16A 4Gang Multi-Function Socket	 Z489 16A 3Gang Switched Socket			

Z SERIES

 Z445 16A 1Gang and 20A Switch	 Z460 16A 1Gang Multi-Function Socket	 Z406 13A 2Gang Switched Socket
 Z408 13A 2Gang Switched Socket with Neon	 Z408R 13A 2Gang Switched Socket	 Z412 13A and 15A Switched Socket with Neon
 Z485 13A Multi-Function Socket	 Z486 15A Multi-Function Socket	 Z488 2x16A 2Gang Switched Socket
 Z432 TV Socket	 Z452 TEL. Socket	 Z469 Satellite Socket
 Z468 TV and Satellite Socket	 Z442 Computer Socket	 Z438 TEL. Socket
 Z220 Dimmer Switch	 Z820 20A Connection Plate	 Z805 25mm Single Cavity Box
 Z810 25mm Double Cavity Box	 Z821 45A Connection Plate	

R SERIES



R301
1Gang 1Way Switch
R302
1Gang 2Way Switch



R303
2Gang 1Way Switch
R304
2Gang 2Way Switch



R305
3Gang 1Way Switch
R306
3Gang 2Way Switch



R317
Bell Push Switch



R318
Bell Push Switch with Neon



R324
20A DP Switch with Neon



R327
45A DP Switch with Neon (7x7)



R329
45A DP Switch with Neon(7X14)



R405
13A 1Gang Switched Socket



R407
13A 1Gang Switched Socket



R429
15A 1Gang Switched Socket



R431
15A 1Gang Switched Socket with Neon

R SERIES



R444
16A 2Gang Multi-Function Socket



R445
16A 1Gang and 20A Switch



R460
16A 1Gang Multi-Function Socket



R406
13A 2Gang Switched Socket



R408
13A 2Gang Switched Socket with Neon



R432
TV Socket



R452
American TEL. Socket



R469
Satellite Socket



R442
Computer Socket




RPN SERIES



RN SERIES





12
YEARS
PROFESSIONAL
NINGBO EVERISING
<http://www.neiec.cn>

SWITCH&SOCKET BAKELITE

W SERIES



W301
1Gang 1Way Switch

W302
1Gang 2Way Switch



W303
2Gang 1Way Switch

W304
2Gang 2Way Switch



W305
3Gang 1Way Switch

W306
3Gang 2Way Switch



W324
20A DP Switch with
Neon



W327
45A DP Switch with
Neon (7x7)



W331
45A Cooker Unit



W405
13A 1Gang Switched
Socket



W428
5A 1Gang Switched
Socket



W408
13A 2Gang Switched
Socket with Neon

AT SERIES



AT301
1Gang 1Way Switch

AT302
1Gang 2Way Switch



AT303
2Gang 1Way Switch

AT304
2Gang 2Way Switch



AT305
3Gang 1Way Switch

AT306
3Gang 2Way Switch



AT407
13A 1Gang Switched
Socket With Neon



AT431
15A 1Gang Switched
Socket with Neon



AT408
13A 2Gang Switched
Socket with Neon

H SERIES

